


THERMOWELL

| | |
|-------------------------|-------------------------|
| <p>TYPE: S01</p> | <p>TYPE: S02</p> |
| <p>TYPE: S03</p> | <p>TYPE: S04</p> |
| <p>TYPE: S05</p> | <p>TYPE: S06</p> |
| <p>TYPE: S07</p> | <p>TYPE: S08</p> |
| <p>TYPE: S09</p> | <p>TYPE: S10</p> |

| | |
|-------------------------|-------------------------|
| <p>TYPE: F01</p> | <p>TYPE: F02</p> |
| <p>TYPE: F03</p> | <p>TYPE: F04</p> |
| <p>TYPE: F05</p> | <p>TYPE: N01</p> |
| <p>TYPE: N02</p> | <p>TYPE: N03</p> |



order : 1. thermowell type
 3. process connection size and rating
 5. thermowell length (u)
 7. material

2. sensor connection thread size / hex length
 4. bore diameter
 6. thermowell diameter (Q Dia & tapered tip Dia)
 8. coated (option)